



New Products



Stocker Star® NA Stock Mount Non-Adjustable Shocks

- **Easy Bolt-In Installation**
- **Deflective Disc Valving** – *Advanced Shock Technology*
Increased valving response, control and consistency.
- **5/8" Centerless Ground, Hard Chrome Plated Piston Rod**
Precision surface eliminates flex, increasing valving consistency.
- **Machined Aluminum Body**
Aluminum for lightweight performance, machined to precise tolerances.
- **Bright Anodized Body**
Unmatched durability, ease of maintenance, show-winning appearance.

- **Three Step Sealing System**
Aerospace material. Exclusively engineered double lip seal with wiper eliminates seal drag and dirt intrusion.
- **Shock Mounting Hardware**
Bushing material exclusive to QA1 shocks for both upper and lower mounts. Mounting hardware is zinc or chrome plated for durability and professional appearance. Polyurethane bushings standard.
- **These shocks are revalveable and rebuildable by QA1 Authorized Service Centers**

Make/Model	Year	Front Part No.	Rear Part No.
BUICK			
Regal (incl. GN)	1973-87	TN505	TN801
Skylark (incl. GS)	1964-67	TN507	TN801
Skylark (incl. GS)	1968-79	TN505	TN801
CHEVROLET			
C-1500 / C-10 Leaf Spring	1963-72	TN403	TN801 ⁵
C-1500 / C-10 Coil Spring	1963-72	TN403	-
C-1500 / C-10	1973-86	TN403	TN901 ⁵
C-1500 / C-10	1987-99	TN507	TN901 ⁶
Camaro (Single leaf)	1967-69	TN505	TN703
Camaro (Multi leaf)	1968-69	TN505	TN802
Camaro	1970-81	TN507	TN702
Camaro	1982-92	-	TN704
Camaro	1993-02	-	TN704
Chevelle	1964-67	TN507	TN801
Chevelle	1968-87	TN505	TN801
Chevy II	1962-67	TN506	TN703
Chevy II	1968-79	TN505	TN801
Corvette	1963-82	-	TN403
Corvette	1984-87	TN511	TN403
Corvette	1988-96	TN511	TN512
Corvette	1997-08	TN510	TN705
El Camino	1964-67	TN507	TN801
El Camino	1968-87	TN505	TN801
Full Size	1955-57	TN507	TN902 ³
Impala / Full Size (incl. S/Sport)	1958-90	TN507	TN801
Impala / Full Size (incl. S/Sport)	1994-96	TN507	TN801
Monte Carlo	1970-88	TN505	TN801
Nova	1962-67	TN506	TN703
Nova	1968-79	TN505	TN801
S-10 Pickup 2WD (excl. Xtreme)	1982-04	TN505	TN901 ¹
DODGE			
Challenger	1970-74	TN501	TN901
Charger	1965-72	TN501	TN901
Charger	1973-76	-	TN901
Coronet	1965-72	TN501	TN901
Coronet	1973-76	-	TN901
Dakota Pickup	1987-96	TN505	TN901 ¹
Dakota Pickup	1997-99	TN505	TN901
Dart	1962-76	TN501	TN901
Demon	1962-76	TN501	TN901
Swinger	1962-76	TN501	TN901
FORD			
Elite	1968-71	TN503	TN509
Elite	1972-76	TN507	TN703
F-150 Pickup (incl. Lightning)	1985-96	TN501	TN901
F-150 Pickup (incl. Lightning)	1997-09	TN502 ²	TN902

Make/Model	Year	Front Part No.	Rear Part No.
FORD Continued			
Fairlane	1966-70	TN503	TN509 ³
Falcon	1960-70	TN503	TN509 ³
Maverick	1969-77	TN401	-
Mustang	1964-70	TN401	TN509
Mustang	1971-73	TN402	TN509
Mustang	1979-93	-	TN706
Mustang (5.0 & 4.6)	1994-04	-	TN706
Mustang (I.R.S. Cobras)	1999-04	-	TN707
Mustang	2005-10	-	TN708
Torino	1968-71	TN503	TN509
Torino	1972-76	TN507	TN703
MERCURY			
Comet	1960-70	TN503	TN509
Comet	1971-77	TN401	-
Cougar	1967-70	TN401	TN509
Cougar	1971-73	TN402	TN509
Cyclone	1968-71	TN503	TN509
OLDSMOBILE			
Cutlass 442	1964-67	TN507	TN801
Cutlass 442	1968-88	TN505	TN801
Omega	1973-79	TN505	TN801
PLYMOUTH			
Barracuda	1964-74	TN501	TN901
Belvedere	1962-72	TN501	TN901
Duster	1960-76	TN501	TN901
Fury / Full Size	1962-64	TN501	TN901
Fury / Full Size	1965-78	-	TN901
Satellite	1962-72	TN501	TN901
Scamp	1960-76	TN501	TN901
Valiant	1960-76	TN501	TN901
PONTIAC			
Firebird / Trans Am (Single Leaf)	1967-69	TN505	TN703
Firebird / Trans Am (Multi Leaf)	1968-69	TN505	TN802
Firebird / Trans Am	1970-81	TN507	TN702
Firebird / Trans Am	1982-92	-	TN704
Firebird / Trans Am	1993-02	-	TN704
Grand Prix	1969-87	TN505	TN801
GTO	1964-67	TN507	TN801
GTO	1968-74	TN505	TN801
GTO	2004-06	-	TN903
LeMans	1964-67	TN507	TN801
LeMans	1968-81	TN505	TN801
Tempest	1964-67	TN507	TN801
Tempest	1968-81	TN505	TN801
Ventura II	1971-77	TN505	TN801

NOTES:

- Due to deviations from the factory ride heights, it may be necessary to check the actual ride height of your particular application.
- These shocks can be converted to different mounting applications.

See www.QA1.net for different mounting options.

FOOTNOTES

1. Requires T-Bar Mounting Kit (part #BAR350).
2. Requires T-Bar Mounting Kit (part #BAR300).
3. Check vehicle ride height before ordering.
4. May require Lower Shock Bolt (part #7888-108).
5. Requires Sleeve Kit (part #SLV750).
6. For use on lowered ride height applications only.
7. Some of the original mounting hardware may be reused. Excluding select ride control. Includes Z06.

All Dimensions are in Inches

Part No	Compressed Height	Extended Height	Upper Mount	Lower Mount
TN401	10.57	14.40	T-Bar	Special
TN402	8.98	13.24	Stud	Special
TN403	10.13	14.00	Eyelet	Eyelet
TN501	10.25	15.50	Stud	Eyelet
TN502	10.25	15.50	Stud	T-bar
TN503	9.59	14.48	Stud	Special
TN504	11.00	16.38	Eyelet	Eyelet
TN505	8.75	13.50	Stud	T-bar
TN506	10.39	15.35	Stud	Special
TN507	9.38	14.38	Stud	T-bar
TN509	11.50	17.00	Stud	Stud
TN510	11.20	16.19	Stud	T-bar
TN511	10.26	15.34	Stud	T-bar

Part No	Compressed Height	Extended Height	Upper Mount	Lower Mount
TN512	9.47	14.47	Stud	Eyelet
TN702 ⁴	13.00	19.63	T-Bar	Stud
TN703 ⁴	12.25	19.00	Stud	Eyelet
TN704	12.35	18.95	Stud	Special
TN705 ⁷	10.88	15.88	Stud	Special
TN706	13.00	20.50	Stud	Eyelet
TN707	13.00	20.50	Stud	Eyelet
TN708	13.00	20.50	Stud	Eyelet
TN801 ⁴	13.50	21.00	T-Bar	Eyelet
TN802 ⁴	13.00	20.50	Stud	Eyelet
TN901 ⁴	14.87	23.87	Eyelet	Eyelet
TN902	14.50	23.50	Stud	Eyelet
TN903	15.50	24.12	Stud	Eyelet