

← FRONT

LINE UP WITH LOWER EDGE  
OF INNER FENDER INDENT

LINE UP CORNER WITH  
BACK OF INDENT

PASSENGER SIDE

## INNER FENDER TRIMMING INSTRUCTIONS

1. Cut out this template along the mid line. The upper portion will be the template while this lower section will only serve as the instructions.



2. Tape the template to the lower edge of the inner Passenger frame indent with print facing engine (as shown). Line up the rear template edge with the back edge of the indent. Mark and cut inner fender along lower template line.

3. Mirror the template to the drivers side with the printing touching the inner fender. The printed "front" will still be towards the front, lining up the template along the lower and rear fender indent as done on the passenger side.

4. Mark inner drivers side fender along lower template and cut out.

***Drivers Side Cut Complete -->***

