



Technical Support Line: (952) 985-5675 Email: sales@QA1.net

INSTALLATION INSTRUCTIONS

QA1 P/N 5267, 5268, 5269 Upper Trailing Arms '73-'88 GM A/G-body, '68-'72 GM A-body, '64-'67 GM A-body

TOOLS AND SUPPLIES REQUIRED

•SAE and/or Metric Wrench Set

Floor Jack

• Jack stands

• Tire Chocks

Blue Loctite™

• SAE and/or Metric Socket Set

• Ball Joint Service Tool

Grease Gun


Figure 1


Torque wrench

REMOVAL OF STOCK TRAILING ARMS


- 1. Place vehicle on a level surface and place tire chocks in front of and behind the front tires.
- 2. Support the rear frame of the vehicle on jack stands and remove the rear wheels.
- 3. Place a floor jack under the differential and lift up slightly to remove tension from the trailing arm bolts. Make sure not to lift the vehicle off the jack stands. (Figure 1)

Note: Keep floor jack under vehicle during the complete removal and installation procedure. Remove only one arm at a time. Removing both could cause the axle to rotate making installation difficult.





- 6. If you are having difficulty removing the trailing arm bolts, remove the lower shock bolts and the rear springs to aid in the removal of the bolt.
- 7. Clean the frame at the trailing arm pivot area with a wire brush and lubricate the old bushing shell before removal.
- 8. Remove the pressed-in factory rubber bushing from axle housing using a ball joint service tool. Some bushings can be removed using a sledge hammer to get the bushing shell mostly out and fully removed by striking the lip of the bushing shell. Note the direction of bushing in the axle housing. Be careful not to damage the axle housing during the removal process. (Figure 2)



INSTALLATION INSTRUCTIONS

1. Install the polyurethane bushing into axle housing, facing the same direction as stock. The bushing should only be installed to the lip on the bushing shell. (Figure 3-5)



Note:

1964 axle housings use smaller bushings than newer cars and require QA1 P/N 9032-383 Bushing Kit. This kit reuses the factory outer bushing shells.


2. Install the polyurethane thrust washer on inboard side of bushing.

Note: Left side only, some thrust washers will require trimming for clearance of the axle housing. If you install the thrust washer at the same time as you install the bushing, it requires less trimming for clearance. On 1978-1988 model year G-body vehicles, using metric stock arm pivot bolts, drill or file front locating hole to ½" diameter to enable use of supplied ½" diameter bolts.

- 3. Using the supplied grease, lube the trailing arm bushings and the axle bushings on the surface that contacts the arms.
- 4. Install the new trailing arms with the grease fittings facing down.
- 5. Install the front bolt first using the thicker ½" washers supplied on the outside of the frame. (Figure 6)
- 6. Place one drop of Blue Loctite™ on clean threads and torque the nut to 70 ft.-lbs. The trailing arm should then pivot smoothly on the chassis.
- 7. Position the trailing arm over the polyurethane bushing and thrust washer. Install rear bolt in the same direction as original and torque to 79 ft.-lbs. (Figure 7) shows the arm installed.
- 8. Repeat for the other side.

Note: Although QA1 trailing arms are pre-lubed, you may want to finish your installation by lubing the front bushing with a grease gun. Be sure to install zerk caps to prevent dirt and corrosion from damaging the fitting. Check all nut and bolt tightness after first 10 miles.







READ ALL INSTRUCTIONS CAREFULLY AND THOROUGHLY PRIOR TO STARTING INSTALLATION. PRODUCTS THAT HAVE BEEN INSTALLED ARE NOT ELIGIBLE FOR RETURN. USE THE PROPER JACKING LOCATIONS. DEATH OR SERIOUS INJURY CAN RESULT IF INSTRUCTIONS ARE NOT CORRECTLY FOLLOWED. A GOOD CHASSIS MANUAL, AVAILABLE AT YOUR LOCAL PARTS STORE, MAY ALSO AID IN YOUR INSTALLATION.

• DISCLAIMER / WARRANTY •

QA1 WARRANTS THAT THE PRODUCTS WILL BE FREE FROM DEFECTS IN MATERIAL AND WORKMANSHIP FOR ONE YEAR FROM DATE OF SALE TO THE ORIGINAL PURCHASER. QA1 MAKES NO OTHER WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. QA1 SHALL HAVE NO OBLIGATION UNDER THE FOREGOING WARRANTY WHERE THE DEFECT IS THE RESULT OF IMPROPER OR ABNORMAL USE, YOUR NEGLIGENCE, VEHICLE ACCIDENT, IMPROPER OR INCORRECT INSTALLATION OR MAINTENANCE, NOR WHEN THE PRODUCT HAS BEEN REPAIRED OR ALTERED IN ANY WAY. QA1'S LIABILITY IN THE CASE OF DEFECTIVE PRODUCTS SUBJECT TO THE FOREGOING WARRANTY SHALL BE LIMITED TO THE REPAIR OR REPLACEMENT, AT QA1'S OPTION, OF THE DEFECTIVE PRODUCTS.

THE USER UNDERSTANDS AND RECOGNIZES THAT RACING PARTS, SPECIALIZED STREET ROD EQUIPMENT, AND ALL PARTS AND SERVICES SOLD BY QA1 ARE EXPOSED TO MANY AND VARIED CONDITIONS DUE TO THE MANNER IN WHICH THEY ARE INSTALLED AND USED. QA1 SHALL BEAR NO LIABILITY FOR ANY LOSS, DAMAGE OR INJURY, EITHER TO A PERSON OR TO PROPERTY, RESULTING FROM THE INSTALLATION, DIRECT OR INDIRECT USE OF ANY QA1 PRODUCTS OR INABILITY BY THE BUYER TO DETERMINE PROPER USE OR APPLICATION OF QA1 PRODUCTS. WITH THE EXCEPTION OF THE LIMITED LIABILITY WARRANTY SET FORTH ABOVE, QA1 SHALL NOT BE LIABLE FOR ANY CLAIMS, DEMANDS, INJURIES, DAMAGES, ACTIONS, OR CAUSES OF ACTION WHATSOEVER TO BUYER ARISING OUT OF OR CONNECTED WITH THE USE OF ANY QA1 PRODUCTS. MOTORSPORTS ARE DANGEROUS; AS SUCH, NO WARRANTY OR REPRESENTATION IS MADE AS TO THE PRODUCT'S ABILITY TO PROTECT THE USER FROM INJURY OR DEATH. THE USER ASSUMES THAT RISK!

Dedicated Technical Support Team

QA1 is dedicated to providing quality support and instructions. We employ passionate racers and car enthusiasts that know our products and the industry to better serve you.

Check out our tech videos at www.YouTube.com/QA1Tech for:

- Frequently Asked Questions
- •Quick Tips
- •Install Information
- Tuning and Repair Guides
- Other technical information

Or call to speak with one of our experts: 1.800.721.7761

*Our technical support and order lines are open Monday - Friday. 8 am to 5 pm CST.



Facebook.com/QA1 Motorsports



witter.com/QA1 Motorsports



Instagram.com/QA1 Motorsports



www.QA1.net/Tech